

Northwestern University

Wireless Sensor Networks and RFIDs

Instructor: Robert Dick
Slides from Randall Berry

Outline:

- Enabling technology trends.
- History
- Single Sensor Node Architecture.
 - Hardware
 - Software
- Design considerations

Design considerations

In addition to performance, much of sensor net design is driven by three (often conflicting) factors:

1. **Cost:** less is better
2. **Size:** smaller is (often) better
3. **Energy-efficiency:** longer lifetime is better

Design Considerations

- **Cost:** Currently \approx \$100
 - Economies of scale could bring this down to $<$ \$10.
 - For some areas \approx \$1 needed to drive adoption.
- **Size:**
 - MEMS and Nano-tech will likely reduce size of chips.
 - Some designs already at \approx 1cm^2
 - except for batteries/sensors
 - In some cases packaging may dominate chip size.
 - Antenna size can also be important.
- **Energy-efficiency:**
 - Some applications require 1-5 year lifetimes.
 - One of the most challenging issues for sensor nets.

Energy Efficiency

- Recall $1\text{ Watt} = 1\text{ Joules/sec.}$
- Total energy in joules
 - Lifetime of a node $= 1/(\text{Watts used})$
- Reasonable lifetimes \Rightarrow operate at low Watts!
- One Christmas tree light = 0.5 W
 - Want Nodes to use $1/10,000^{\text{th}}$ of this on average!

Energy Efficiency

- Typical energy sources
 - Non-rechargeable coin-size or AA battery:
 - stores \approx 3 watt-hours.
 - Shelf life of \approx 5 years.
 - Lithium-Thionyl Chloride AA battery
 - \approx 8 watt-hours.
 - More expensive.
- Example energy consumption:
 - Micro-controller: 10mW
 - Short-range radio: 20 mW
- Typical battery at 30mW lasts $<$ 5 days!

Energy efficiency solutions?

1. Find better energy sources
2. Lower energy consumption

Better energy sources

Battery technology is fairly mature.

- current power density is within 1000 of that of nuclear reactions/ within 2-10 of fuel cells.

Renewable sources:

- **solar cells:** power density = 15mW/cm² in direct sun. drops to 0.15mW/cm² in clouds.
- Other forms of scavenging have even lower power densities.
- In some cases replenishment/energy delivery possible.

Energy efficiency solutions?

1. Find better energy sources
2. Lower energy consumption

Energy Consumption

- **Computation and Communication** are main energy consumers.
- Excessively writing to FLASH memory can also impact memory.
 - Reading requires less energy.
 - Reading/writing to on-board memory considered part of processing power.
- Most sensors use little energy
 - Exceptions are active sensors.
 - A/D costs can be important for large data streams.

Processing power

- Processing power:
 - Integrated circuits require power each time a transistor pair is flipped.
 - In CMOS:

$$\text{Power} = 0.5 C V_{dd}^2 f$$

C = device capacitance (related to area)
V_{dd} = voltage swing
f = frequency of transitions (clock speed).

Processing power

$$\text{Power} = 0.5 C V_{dd}^2 f$$

- Moore's law decreases C.
- What about V_{dd} and f?
 - Decreasing f slows down processor.
 - Decreasing V_{dd} has similar effect, indeed:

$$\frac{1}{f} \propto \frac{V_{dd}}{V_{dd} - V_t^2}$$

- **Dynamic voltage scaling (DVS)** – adjust V_{dd} and f in response to computational load.

DVS example

Suppose a processor can be scaled from 700Mhz at 1.65 V to 200 Mhz at 1.1 V.

What is reduction in power and speed?
Energy/instruction?

Processor alternatives

Year	ASIC	FPGA	Microprocessor
1999	1 pJ/op	10 pJ/op	1 nJ/op
2004	0.1 pJ/op	1pJ/op	100pJ/op

- As noted earlier ASICs and FPGAs have better energy efficiencies.
 - Less flexibility/higher costs.
- All “ride Moore’s law” at roughly the same rate.

Dynamic power management

- When “on” processors consume power even if idle (e.g. generating clock signal)
- In most sensor nodes, only need to be “active” a small fraction of the time.
- Can conserve power by putting processor into various “sleep” modes when not active.

Dynamic power management

- Most microcontrollers provide one or more sleep states.
 - Difference is in how much of the chip is shut down.
 - Note some Energy is required to change state
 - Usually more Energy to return to active the deeper the sleep.

Dynamic power management

Example: Intel StrongARM microcontroller

3 modes:

- *Active mode* – all parts powered, consumes up to 400mW
- *Idle mode* – CPU clock stopped, clocks for peripherals are active, power consumption = 100 mW.
- *Sleep mode* – only real-time clock remains active. Wake-up only via timer, power consumption = 50μW

Dynamic power management

Example continued:

Given 5000 Joule battery, controller will operate for

$$5000 \text{ J}/400\text{mW} = 12500 \text{ sec} = 208 \text{ minutes}$$

If active only 1% of the time, can extend this to ≈ 14 days

Communication Power

Energy consumption in radio transmission:

1. Energy radiated by the antenna.
2. Energy consumed by needed electronic components (oscillators, mixers, filters.)

The second component is also present when **receiving**. (or even if just “listening”).

Radiated energy

- Amount of radiated energy depends on distance to receiver and target transmission rate.
 - I.e. need to transmit enough energy to get target SNR at receiver.
 - For given rate: $P_r \propto d^\alpha$, $\alpha \approx 4$ for most sensor nets.
- Also depends on antenna type/power amplifier.
 - For small sensors, antennas maybe in efficient.
 - Power into power amp often ≈ 4 times transmitter power

Communication Energy

- Circuit energy is roughly constant and independent of distance.
 - on the order of 1-10mW
- For large distances, transmission energy dominates.
- For short distance, circuit energy should also be considered.

Communication Energy

Example: For a particular radio the power consumption while on is 2mW. When transmitting at a peak power of 10mW the power amplifier has an energy efficiency of 25%.

What is total power while transmitting?

Communication power and multi-hop

- Are two hops better than one?

Processing vs. transmitting

- For motes transmitting 1-bit costs same as executing $\approx 1,000$ processor instructions.
- Can save on transmission costs by intelligently processing data before transmitting!
- Data aggregation/fusion.

Data fusion example

- Averaging in network vs. averaging outside.

Dynamic power management

- Dynamic power management also useful for communication power.
- Turn radio off when nothing to send/receive.
- Note while off can **not** receive.

Dynamic power management

- Taking into account DPM can change transceiver trade-offs.
 - e.g. is it better to send at high rate for short time and sleep or slow rate for longer time?

Hibernation

Key Issue: when to wake-up?

Possibilities:

1. At regular intervals
 - need synchronization
2. Trigger by stimulus
 - e.g. heat sensitive circuit.

Network Size Issues

- Energy efficiency and network size.

Heterogeneous network

- Another way to reduce power is to have nodes with heterogeneous capabilities.

Possible design trade-offs:

- Millennial Net “I-Bean” sensor platform
 - 10-year life at “normal sampling mode” (once per 100 sec.) with coin-size lithium battery.
 - But only limited transmission range (30m)
 - Vs. \approx 300m with MICA-2

